

- 1.) Remove 4-40 hardware screws from the back of the modem.
- 2.) Orient the modem in the desired direction on the L-Bracket.
- 3.) Replace the screws removed in step 1 through L-Bracket into modem.
- 4.) Using two 4-40 x 1/4" screws and two #4 split lock-washers fasten L-Bracket and modem to mounting panel
- 5.) Mount panel to equipment rack using rack mounting clip and hardware supplied with 19" equipment rack.

